

TOSOT Parts Diagram

34	Air Louver
33	Guide Louver
32	Test Board Assy
31	Remote Controller
30	Connecting Cable
29	Connecting Cable
28	Power Cord
27	Electric Box Cover
26	Shield Cover of Electric Box Cover
25	Electric Box Cover Sub-Assy
24	Main Board
23	Jumper
22	Terminal Board
21	Axile Bush
20	Electric Box Assy
19	Crank
18	Stepping Motor
17	Rubber Plug (Water Tray)
16	Connecting pipe clamp
15	Fan Motor
14	Cross Flow Fan
13	Wall Mounting Frame
12	Evaporator Assy
11	Cold Plasma Generator
10	Evaporator Support
9	Gasket sub-assy of Bearing
8	Ring of Bearing
7	Drainage Hose
6	Rear Case Assy
5	Left Axile Bush
4	Helicoid Tongue
3	Front Case Assy
2	Display Board
1	Front Panel Assy

